



Ricoh Ri100 Printed Mask

Use the Ricoh Printer Mask.jpg pattern to print not only the Juki and QVP logo but also to print the mask pattern. Simply cut out the mask on the lines, and sew together. We have also included a .jpg of just the mask outline. Load the mask pattern into the printer software and add your graphics.

Supplies Needed:

- Ricoh Ri100 Printer
- Ricoh Finisher
- Juki Sewing Machine
- White cotton fabric 12" x 16"
- Lining Fabric 9" x 12"
- 2 pcs elastic 7" long
- Thread for sewing mask
- Nose bridge aluminum strip (optional)



Ricoh Ri100 Printer:

1. Open Ricoh Design Software > Advanced Designer.
2. Garment Type - Other > Garment Thickness - Normal > Orientation - Portrait > OK.
3. Import Image > Computer > Select Image.



Computer, SD/microSD Card
USB Memory

4. Navigate to where the Ricoh Mask Pattern.jpg file is saved and open the file.
5. Place the white cotton fabric on the printer platen.
6. Print the mask pattern.

Sewing Instructions:

1. Cut out the pattern.
2. Place the pattern pieces on the lining fabric and cut out.
3. Thread machine and bobbin with matching thread.
4. Sew the center seam on both the mask front and mask lining.
5. Sew the front mask to the lining, right sides together.
6. Turn right side out and press.
7. Finish the edges on each end of the mask.
8. Turn under edges 1/4" and press.
9. Place elastic on each end and top stitch down.
10. Attach Nose Bridge Aluminum Strip to mask (optional).